



ROCK CRAWLER



USER MANUAL

OFF-ROAD CRAWLER

NO.EX86190



Notes:

- ⇒ Read and understand the instructions carefully before operating or assembling your racing model.
- ⇒ Specifications are subject to change without prior notice, and actual received model may vary from the images and/or descriptions in this manual.

The product has conducted IQC (Input Quality Control) and full inspection before delivery. The manufacturer is responsible for quality assurance. Remote Control model is assembled manually, and then there may have some defects in the production process. Once the product is modified or incorrect operation, it cannot apply for replacement and return services, for the parts and accessories may be damaged. Please contact the retail seller for after-sales service when needed.

The product conforms to technical requirements of export safety regulations.



Please read and follow all the instructions in the manual before use.

MADE IN CHINA

Factory Address: Huang Jiang Town, Dong Guan City, Guang Dong Province, China

Production Date: refer to packing instruction



Introduction

We would like to welcome you to the world of remote control cars. What are RC cars? The simple answer is that they are radio controlled cars that respond precisely to your command. The more complete answer is that they can be a great addition to your lifestyle. RC car building and racing teach valuable mechanical and electrical skills, promote teamwork and encourage racers to test their skills with other racers from around the world. Whether you are just having fun racing your car in your backyard or racing at the world competition contest, radio controlled car racing is a great hobby.

We has been making RC products aimed at making our hobby fun and exciting with an affordable price. We are confident that your experience with our products will be positive. Of all the radio controlled models out there, no question about it, RC cars are the hardest to operate. This user manual covers a wide range of topics from nitro powered remote control cars to electrical powered remote control cars. We highly recommend that you read this user manual throughly and carefully before assembling and operating. Please follow all precautions and recommendations located within the manual. Be sure to retain the manual for future reference, routine maintenance, and tuning.

This product is not a toy. It is not recommended for children under 14 years old and any minor should be accompanied by an adult when operating. This product is a precision machine that requires proper assembly and setup to avoid accidents. Failure to take caution when operating this product may result in serious injury or property damage. It is the owner's responsibility to operate this product in a safe manner. Manufacturer and its distributors are not responsible in any way for any and all bodily injury(s) and/or property damage that may occur from the use of or caused by in any way or this product.

Warnings

- The product is not intended for those under 14 years of age without proper adult supervision. The product is not a toy. It is a precision machine requiring proper assembly and setup to avoid accidents and it is the responsibility of the owner to operate this product in a safe manner as it can cause serious personal injury and damage to property due to carelessness or misuse.

- Do not attempt to disassemble or modify any of the product components without the assistance of an experienced RC user.

- Only use the correct type of battery to operate. Using any wrong type of battery will damage the product and possibly make it dangerous to operate.

- The motor(s) may get hot during use. Always allow 10-15 minutes between each operation for the motor to cool down. This will prolong the life of your product.

- Choose an appropriate operating site consisting of flat, smooth ground, and clear open field. Do not operate near buildings, high voltage cable lines, or trees to ensure safety operation. Operate in safe area only, away from other people. RC models are prone to accidents, failures, and crashes due to a variety of reasons including, lack of maintenance, user error, and radio interference. Users are responsible for their actions and damage or injury occurring during the operation.

- Do not operate in inclement weather, such as rain, wind, snow or darkness.

- The product is composed of precision electrical components. It is critical to keep the product away from moisture and other contaminants. Do not allow them to get wet. Electrical damage may occur that could affect safe operation.

- You should complete a successful pre-run check of your radio equipment and model prior to each run.

- Use replacement parts from the original manufacturer to ensure safe operation.

- Operate this product within your ability. Do not operate under tired condition

- After each use, always allow the battery to cool down before recharging. When charging the battery pack, do not overcharge! If batteries get hot during charging, discontinue charging immediately and disconnect the battery from the charger. Never leave battery unattended while charging. If you are unsure of how to charge this battery, please seek the advice of experienced RC users. Never let children charge the battery without adult supervision.

- Always turn on the transmitter before connecting the battery on the model. When turning off the model, always disconnect the battery first, and then turn off the transmitter. If the order is reversed, the model may become uncontrollable and cause serious damage.

- If you are in doubt of your ability to operate the model, we strongly recommend that you seek assistance from experienced RC users or join your local modeling club to gain the required knowledge and skill. As the manufacturer and distributor, we assume no liability for the use of this product.

- Before turning on your model and transmitter, please check to make sure no one else is operating under the same frequency. Frequency interference can cause your model, or other's models to crash. The guidance provided by experienced RC users will be valuable for the assembly, tuning, trimming, and actual first flight.

- Never allow batteries to run low or you might lose control of the model.




- Plastic is very susceptible to damage or deformation due to extreme heat and cold climate. Do not store the model near any source of heat such as oven or heater. Store the model indoors, in a climate-controlled, room temperature environment.



- Never shorten the receiver antenna; or this might affect the transmitting range of the radio system.

- This product is a RC hobby model, do not use for other purpose.

Safety

Pay close attention to the following symbols and their meanings. Failure to follow these warnings could cause damage, injury or death.

 Danger	Not following these instructions may lead to serious injuries or death.
 Warning	Not following these instructions may lead to major injuries.
 Attention	Not following these instructions may lead to minor injuries.


 Prohibited	<ul style="list-style-type: none">■ Do not use the product at night or in bad weather like rain or thunderstorm. It can cause erratic operation or loss of control.■ Do not use the product when visibility is limited.■ Do not use the product on rain or snow days. Any exposure to moisture (water or snow) may cause erratic operation or loss of control.■ Interference may cause loss of control. To ensure the safety of you and others, do not operate in the following places:<ul style="list-style-type: none">● Near any site where other radio control activity may occur● Near power lines or communication broadcasting antennas● Near people or roads● On any body of water when passenger boats are present■ Do not use this product when you are tired, uncomfortable, or under the influence of alcohol or drugs. Doing so may cause serious injury to yourself or others.■ The 2.4GHz radio band is limited to line of sight. Always keep your model in sight as a large object can block the RF signal and lead to loss of control.■ Do not touch any part of the model that may generate heat during operation, or immediately after use. The engine, motor or speed control, may be very hot and can cause serious burns.
 Mandatory	<ul style="list-style-type: none">■ Misuse of this product may lead to serious injury or death. To ensure the safety of you and your equipment, read this manual and follow the instructions.■ Make sure the product is properly installed in your model. Failure to do so may result in serious injury.■ Make sure to disconnect the receiver battery before turning of the transmitter. Failure to do so may lead to unintended operation and cause an accident.■ Ensurethatallmotorsoperateinthecorrectdirection.Ifnot,adjustthedirection first.■ Makesurethemodelstayswithinthesystemsmaximumrangetopreventlossof control.

Thanks for purchasingour RC car. The power system forRC model canbe very dangerous, so please readthis manual carefully. In that we have no control overthe correct use, installation, application, or maintenance of our products, no liabilityshall be assumednor accepted for any damages, losses or costs resultingfrom the use of the product. Any claims arisingfrom the operating, failure of malfunctioningetc. will be denied. We assume no liability for personal injury, consequential damages resultingfrom our product or our workmanship.



START GUIDE

1. Please read the manual carefully and prepare the following things before use.



2. The items inside the box.

One car



Transmitter



Manual



Decal Sheet

Spare Tyre Accessories




Main-Drive Assembly Cover



Wipers


3. Please check the whole product condition when open the package.

Take out the body clips from vehicle bottom, Unplug the light connector, and take out the car body.



- 3-1. After each day of running, you should check your shocks for adequate fluid. If the fluid is low, or it is getting dirty, you should change the fluid in the shocks. To achieve better performance, you may also want to change the shock fluid and or the pistons.
- 3-2. Gear mesh is the clearance between the pinion and spur in an electric car or clutch bell and spur in a nitro car. It has impact on the vehicles performance. If the gear mesh is not set properly you may also damage the clutch bell and spur or the pinion gear and spur gear as soon as the vehicle starts running.
- 3-3. Please check if the screw is tight enough before use. Screw it tight (or apply the screw glue if necessary)
- 3-4. Regularly check and verify the tires are intact. No breach should be observed. Please apply the CA glue if needed.

4-1. Install Charged Batteries In Car.




4-2. Battery Specifications for Product

WARNING:

NO battery includes in factory. Recommend? battery: 2S~3S LIPO battery or 5-9 cells NIMH battery (please match the ESC mode with the corresponding battery type) Pay attention to the battery size and plug specification when purchasing. The maximum battery measurement is 142*48*55mm (LxWxH).

This product can use the 2S or 3S Li-Po battery.



NOTICE

Please check the battery voltage before use. Please use a qualified charger to charge the newly purchased battery. (please read the charging steps in manual when necessary)

Charge the vehicle battery

- Connect charger plug with mains jack and then connect with connector of battery.
- Please be care of safety while charging, please remove charger plug from the mains jack once finish charging. Will be over heat if it is too long to be charging or incorrect charging way. must stop charging if over 45 degree for the battery temperature.
- Do not charge for battery at once when you take it away from your car. Please make sure battery in cool condition before recharge battery to keep battery performance running well and get a longer use life.


NiMH Battery Instructions

- Never dispose of NiMH batteries in a fire or store near sources of heat.
- Only use the supplied NiMH charger to charge the NiMH battery. Using another charger may permanently damage the battery and surrounding components and may also lead to injury.
- Batteries should only be charged on a fireproof surface, away from any flam-mable materials.
- Never leave the battery unattended when charging or discharging.
- Batteries must be discharged or fully exhausted before being disposed of. Cover exposed poles with adhesive tape to prevent short-circuiting!
- Never disassemble or alter the battery contacts. Do not damage or puncture battery cells. Doing so would result in an explosion hazard!
- Keep the NiMH battery away from children.


Lithium Polymer (LiPo) Battery Warnings

- Never charge a lithium polymer battery with a charger designed for NiCd, NiMH, or any other type of battery chemistry. Use ONLY charger designed for LiPo battery.
- Do not leave LiPo battery unattended during charging.
- Do not overcharge the battery.
- Always place the battery on a heat resistant surface alone when charging.
- Always put the LiPo battery inside a charging protection coatner while charging.
- Do not allow LiPo cells to overheat at any time. Cells which reach greater than 140 Fahrenheit (60C) will usually become damaged and will catch fire.
- Do not charge LiPo cells on or near combustible materials including paper, plastic, carpets, vinyl, leather, and wood. inside an R/C modl or full size automobile.
- Do not discharge LiPo; doing so will damage the battery.
- Do not expose LiPo cell to water or moisture at any time.
- Do not store battery near open flame or heater.
- Do not assemble LiPo cells or pre-assembled packs together with other LiPo cells or packs.
- Always store LiPo battery in a secure location away from children.
- Always remove the LiPo battery if model is involved in any kind of crash. Carefully inspect the battery and connectors for even the smallest damage. CAUTION: cells may be hot!
- Do not allow the electrolyte to get into eyes or on skin. Wash affected areas immediately if they come into contact with electrolyte. Do not alter or modify connectors or wires of a LiPo battery pack.
- Always inspect the condition of the battery before charging and operating.
- Do not short circuit the LiPo battery.
- Do not have contact with a leaky/damaged battery directly.
- Do not charge battery out of recommended temperature range (0C - 45C).

4-3. Scheme of installation



6-1. 2.4GHZ Radio System



Install The Transmitter Batteries

Battery Installation:


1. Open the battery compartment cover.
2. Insert 4 AA fully charged batteries or 2S Li-Po batteries in correct polarity. (No response if battery polarity reversed.)
3. Close battery compartment cover.

Binding Process:



1. Press receiver button, LED indicator fast flashing means entering into binding mode, the receiver will automatically looking for the nearest transmitter signal.
2. The indicator will always ON after successful bond.

Batteries: 4 x 1.5 V "AA" (not included)


6-2. Transmitter Steering Trim and Throttle Trim



6-3. Transmitter Steering and Throttle Instruction




6-4. Light Control Usage




6-5. Operating the Lock Differentials

The switch on top of the transmitter operates CH5/CH6 the front and rear differential locking mechanism. The differentials can be locked or unlocked at any time during most driving conditions. If the model is stuck and there is wheelspin on a single wheel (one side of an unlocked differential is freewheeling), then release the throttle and allow the wheels to stop before locking the differential. Apply throttle slowly until the differentials fully engage or disengage.

! The front and rear diff lock is locked in factory. Ensure the vehicle in static or slow driving to avoid gear sweeping when conversion operation on the front and rear diff lock.




6-6. Shifting the High-Low Transmission



7. User Manual of Water-Proof Brushed Speed Controller

WP-1060-BRUSHED



FEATURES

- *. Water-proof and dust-proof for all weather races.
- *. Small size with built-in capacitor module.
- *. Automatic throttle range calibration, easy to use.
- *. Multiple protections: Low voltage cut-off protection for Lipo or NiMH battery / Over-heat protection / Throttle signal loss protection.
- *. Easily programmed with the jumpers.

Model		WP-1060-BRUSHED
Cont. / Burst Current		Forward: 60A / 360A Backward: 30A / 180A
Input		2-3S Lipo, 5-9 Cells NiMH
Cars Applicable		1:10 on-road, off-road 1:10 Crawler, Tank & Boat
Motor Limit	2S Lipo or 5-6 cells NiMH	540 or 550 size motor ≥ 8T or RPM <45000 @7.2V
	3S Lipo or 7-9 cells NiMH	540 or 550 size motor ≥ 13T or RPM <30000 @7.2V
Resistance		Fwd: 0.0008Ohm, Bwd : 0.0016Ohm
Built-in BEC		3A/6V (Switch mode BEC)
Dimension& Weight		36*30*18, 40g



Attention: The incorrect polarity will damage the ESC immediately. If the motor runs in the opposite direction, please swap these two wire connections.

【PROTECTION FUNCTIONS】

1. Low voltage Cut-off (LVC) protection: If the voltage of battery pack is lower than the threshold for 2 seconds, the ESC will enter the protection mode. When the car stops, the red LED blinks to indicate the low voltage cut-off protection has been activated.

Table A: LVC protection for WP-1060-BRUSHED, (F/B/R or F/B mode).

2S Lipo	3S Lipo	4S Lipo	5-9 cells NiMH
Output reduces 50% at 6.5V Output cuts off at 6.0V, cannot be recovered	Output reduces 50% at 9.75V Output cuts off at 9.0V, cannot be recovered	Output reduces 50% at 13V Output cuts off at 12V, cannot be recovered	Output reduces 50% at 4.5V Output cuts off at 4.0V, cannot be recovered


2. Over-heat protection: When the internal temperature of the ESC is higher than 100 Celsius degree or 212 Fahrenheit degree for 5 seconds, the ESC will reduce and cut off the output power. When the car stops, the red LED blinks to indicate the over-heat protection has been activated. If the ESC cools down to 80 Celsius degree (176 Fahrenheit degree) the output power is recovered to normal state.
3. Throttle signal loss protection: The ESC will cut off the output power if the throttle signal has been lost for 0.1 second. The Fail-Save function of the radio system is strongly recommended to be activated.

【TROUBLE SHOOTING】

Trouble	Possible Reason	Solution
After power on, motor can't work, no sound is emitted, and LED is off.	The ESC doesn't get its working voltage; Connections between battery pack and ESC are broken.	Check the battery wires connection or replace the defective connectors.
	Switch is damaged.	Replace the switch.
After power on, motor can't work; red LED blinks.	Throttle signal is abnormal.	Check the throttle wire connection; make sure it is plugged into the throttle channel of the receiver.
	Automatic throttle range calibration is failed.	Set the TRIM of throttle channel to 0 or turn the knob to its neutral position.
The car runs backward while giving throttle. (The motor runs in the opposite direction)	The wire connections between ESC and the motor need to be changed.	Swap two wire connections between the ESC and the motor.
The car can't go backward.	The jumper position is wrong.	Check the jumper and plug it to the correct position.
	The neutral point of throttle channel is changed or drifted.	Set the TRIM of throttle channel to 0 or turn the knob to its neutral position.
The car can't go forward, but can go backward.	The direction of throttle channel is not correct.	Reset the direction of throttle channel from original NOR to REV or from original REV to NOR.

Please review the ESC manual for more details.

8. EX86190 RESCUER Specifications



Item No	Ex86190	Wheel	120*45mm	Motor	550/8020
Item Name	RESCUER	Clearance	70mm (classis) 54mm (steel)	Servo	25kg*1p/ 9g*3p
Scale	1/10	Weight	3.56kg(No battery)	Gear Ratio	26.6:1(H), 50.4:1(L)
Description	RTR-Crawler	Radio/Rx	2.4G/6CH(X6-P1)	Breakover	25.3°
Drive Type	4WD	R/C Distance	<120m>100m	Approach	53.5°
Length	582mm	Battery Recommendations	2S or 3S Lipo, 5-9 Cells NIMH Battery	Departure	40°
Width	248mm	Battery Size	<142*48*55mm(L*W*H)	Body Color	PC Black/white/Yellow
Height	300mm	Number Of Differentials	"Steel"2P	Gift Box Size	630*285*325mm
Wheel Base	324mm	ESC	WP-1060 / 60A	Piece per Carton	1P


9. All the ways done, your car is ready to run. Hope you enjoy the fun in driving it.

Tip: Always turn off the receiver and then the transmitter when not in use. Clean the car before storage.

Vehicle Maintenance:

- 1). Please remove the battery pack plug or take it out, when the car is out of use.
- 2). Before each use, please redo the above steps and check all the parts condition if over wear.
- 3). Ensure the unused battery pack over-discharge (recommended to be above 40%), and keep in a dry and cool place, out of reach of children.
- 4). After each use, please carefully check all the parts condition, and repair or replace the worn part. Use a fine brush to sweep the sand, marl and other dirt inside the model, then wipe it cleanly by a soft cloth.


10. Vehicle parts




11. Troubleshooting

Problem	Possible Cause	Solution
Car does not respond during operation	Electronic plugs loose or fall off	Switch off and reconnect
	Vehicle battery not charged, activating the ESC low voltage cut-off to protect the battery	Replace/recharge the vehicle battery
	Motor or ESC dirty or damaged	replace new Motor (recommend to purchase facoty Motor)
	ESC failed	replace new ESC (recommend to purchase facoty ESC)
	ESC power off by overheated Motor	Stop operation and cool the ESC or Motor
	Motor overheated, demagnetized or damaged	replace new Motor (recommend to purchase facoty Motor)
	Transmitter batteries low or beyond the remote control distance	Replace the transmitter batteries, adjust the remote control distance
	Transmitter damaged	Relace or contact seller
No Backward, forward normally	ESC "operation mode" setting error	Refer to manual "ESC" , set "operation mode " into "forward and backward reverse with brake"
	ESC damaged	Relace or contact seller
	Throttle damaged or transmitter throttle not centered	Refer to manual "Transmitter", and reset
Car operate automatically, with no control	Throttle trim out of center on transmitter	Refer to manual "Transmitter", and reset
	Neutral throttle is in incorrect position	Adjust ESC in neutral point
Normal operation, speed shift failure	Error Operation	Ensure to operate in stop status, more refer to the Manual
	Gear Cable damage or loose	Replace the accessory or Readjust
	Servo wire inserts in wrong Receiver slot	Refer to the manual, Readjust
Sluggish Action	Battery damaged / not charged	Check, change or recharge
	Throttle trim out of center on transmitter	Adjust (refer to manual "transmitter")
	Motor dirty/ damaged	Clean/ replace
	Drivetrain dirty / damaged	Check and clean
Light Function Failure after Battery properly installed	Light Plug is not connected or in wrong postion	Check the plug connection
	Transmitter Set Error or Light Control Panel Damage	Reset the Transmitter. Otherwise, please check the light control panel is damaged or not.
	Light Cable in wrong installation and connection	Readjust the installation and Connection
Lack of streering and throttle	ESC power off by overheat	Stop operation, cool the ESC
	Transmitter too near interfere electronical objects	Check and rebind transmitter and receiver, refer to manual
Vehicle moves left / right without steering input	Steering accessories damaged	Check and replace
	Wheel loose	Check and replace
	Drivetrain dirty / damaged	Check and replace
Controls Reversed	ST. REV or TH. REV	Change switch position, refer to manual
	Check the wires between ESC and Motor correct or not	Switch the motor black and red wire
Clicking noise in operation	Check the bodysHELL damaged or fall off	Retrim or replace
	Loose or tight between motor gear and main gear	Reset gear mesh
	Gear damaged or rocked	Remove gear cover and inspect. If necessary, replace gear
Only steering, no forward and backward	ESC failed or abnormal	Reset the neutral point or replace
	Transmitter failed or abnormal	Relace or contact seller


Transmission Assembly-1




Transmission Assembly-2




Motor/Transmission Assembly




Diff.gear Assembly




Front Axle Assembly




Rear Axle Assembly




Diff.Lock Line Assembly (Front)



Diff.Lock Line Assembly (Rear)




Diff. Lock Clasp (F-1)




Diff. Lock Clasp (F-2)



Diff. Lock Clasp (R-1)





Diff. Lock Clasp (R-2)




Front Diff. Illustration


Rear Diff. Illustration



Rear Axle Transmission illustration



Front Gear Transmission (Right)




Front Gear Transmission (Left)


Shock Absorber Assembly




Front Axle Assembly




Linkage Bar Assembly




Front Steering Linkage Installation













Front Suspension Linkage Installation




Rear Suspension Linkage Installation







Installing Reer Axle Complete






(Left)




(Right)



Installing Wheel Complet To Vehicle




Mudguard Assembly




Install Mudguard To Vehicle



Front Bumper Assembly




Installing Battery Holder Installing ESC




Installing Receiver




Headlight/Taillight Installation







Installing Top Rack




Pre-Assembled Interior ornaments(R86631)
































Body Decorations



Installing Hood Locks


























Spare Part				
R86545	R86546	R86547	R86548	R86549
				
Front Bumper	Rear Bumper	Bumper Mount	Front Housing	Rear Housing
R86550	R86551	R86552	R86553	R86554
				
Steering HubCarriers	Transmission Housing Lid	Front Gear Box Lid	Rear Gear Box Lid	Baffle A(L/R)
R86555	R86556	R86557	R86558	R86559
				
Shock Plate(L/R)	Baffle B(L/R)	Foot Pedal	Battery Tray	Body Mount(F/R)
R86560	R86561		R86562	
				
Transmission Box A	Transmission Box B		Bumper	
R86563	R86564	R86565	R86566	R86567
				
Servo Mount	Motor Cover Upper	Motor Cover Front	Caster Mount	Chassis Mount
R86467	R86468	R86469	R86470	R86471
				
ESC Mount	Receiver Box	Lock Diff Button	Differential Box	Front Driveshaft
R86472	R86473		R86474	
				
Rear Driveshaft	Dig Servo Parts		Link Ends	

Spare Part				
R86475	R86631	PVC Cockpit+Sticker	R86630	
				
Shock Absorbers	Pre-Assembled Interior ornaments	R86629-0(Clear) R86629-1(Black)		
R86478	PC Body+Sticker		Pre-Assembled PC Body	
				
PC Body Hood(Clear)	R86479 (Clear) R86480-1(Black) R86480-2(White) R86480-4(Grey)		P86480-1(Black) P86480-2(White) P86480-4(Grey)	
R86481	R86482	R86483	R86484	
				
Body Assembled Part	Lamp-Chimney(Clear)	Lamp-Socket(Rear)	Air Grill / Lamp-Socket(Front)	
R86485	R86486	R86487	R86488	R86489
				
Rear Body Plate	Rear View Mirror	Hood Switch	Tank	Roof Rack
R86490		R86491	R86492	R86493
				
Chassis Rails		Panhard Bar Link	Link 72.5mm	Link 100mm
R86497		R86494	R86495	R86496
				
Front/Rear Lock Diff Line		Link 108mm	Link 110.5mm	Link 113mm
R86498	R86499	R86500	R86501	R86502
				
Diff Main Gear(40T)	Drive Gear(16T)	Diff Bevel Gear Set	Transmission Gear(9T)	Transmission Gear(6T)

Spare Part				
R86503	R86504	R86505	R86506	R86507
Transmission Gear(20T)	Transmission Gear(17T)	Transmission Gear(13T)	Transmission Slider	Gear Stick
R86508	R86509	R86510	R86511	R86512
Pinion Gear(17T)	CVD Drive shaft	Rear shaft	Driveshaft	Gear Shaft 1
R86513	R86187	R86514	R86515	R86516
Crown Gear (64T)	Sping	Slipper Spacer/Plate	Differential Lock	Gear Shaft 2
R86517	R86518	R86519	R86520	R86521
Gear Shaft 3	Gear Shaft 4	Gear Shaft 5	Ball Bearingφ15*φ21*4	Ball Bearingφ12*φ18*4
R86522	R86523	R86524	R86525	R86526
Ball Bearingφ10*φ15*4	Ball Bearingφ7*φ14*4	Ball Bearingφ7*φ11*3	Ball Bearingφ5*φ11*4	Ball Bearingφ4*φ8*3
R86045	R86527	R86048	R86052	R86528
King Pin Bushing	Ball Stand φ4mm	Ball Stand φ5.9mm	Flange M4 Lock Nut	Nylon Nut M2.5
R86379	R86058	R86059	R86060	R86061
Button Head 2*4mm	Button Head 3*6mm	Button Head 3*8mm	Button Head 3*10mm	Button Head 3*12mm

Spare Part				
R86062	R86065	R86066	R86529	R86530
Button Head 3*14mm	Button Head 3*20mm	Button Head 3*25mm	Button Head Self-tapping 2*6mm	Step Screws 4*11.5mm
R86071	R86531	R86532	R86072	R86163
Cap Head 2.5*8mm	Cap Head Self-tapping 2*8mm	Flat Head 3*6mm	Flat Head 2.5*10mm	Flat Head 3*10mm
R86533	R86568	R86534	R86535	R86536
Crub Screw Bolt 3*18mm	Shock Shaft	O Ring2.8*1.9mm*8P O Ring2.8*2.0mm*8P O Ring10*1mm*4P	E-Clips - φ2.5mm*6P E-Clips - φ4mm*6P	Pin -2*10mm*6P Pin -2*11mm*6P Pin -2*12mm*6P
R86537	R86569	R86539	R86540	R86541
φ2.6*φ6*0.5 Metal Washer	Wheel Hex	Dig Servo 9G /7.4V	Steering Servo 25KG	Servo Horn(25T)
R86538	X8E(GS07)-150	X6DC	R86772	R86769
Motor-550/8020	Radio/Receiver X6DC	Rexeiver	Light	Magnetic Adapter Cable
R86771	R86024	R86338	R86457	R86477
Body Clip Mount	Linght Clip 2*6	ESC -60A	Flange Head Screws3*8	Rear Fender
R86439	R86466	R86476	R86773	R86774
Wheel Rim(Gun Gray)	Tire W/Foam	Wheel Complete L/R (Gun Gray)	Wheel Rim(Black)	Wheel Complete L/R(Black)

Spare Part				
R86633		R86808		
<div><p>Front Rear</p><p>Pre-Assembled Housing</p></div>		<div><p>Body Decal Stickers</p></div>		
Upgradable Optionals				
R86366		R86544		P860079
<div><p>3*6 3*8 3*8</p></div>		<div><p>PVC Rain Shield</p></div>		<div><p>54MM</p><p>Adjustable LED Lamp</p></div>
P860077		P860065	P860066	P860094
<div><p>145MM</p><p>Adjustable LED Lamp</p></div>		<div><p>Wheel (AL.)</p></div>	<div><p>Wheel (AL.)</p></div>	<div><p>Copper Wheel Weight Set 128g</p></div>
P860086	P860087	P860088	P860089	P860090
<div><p>(AL.)</p><p>Steering HubCarriers</p></div>	<div><p>(COPPER)</p><p>Transmission Housing Lid</p></div>	<div><p>(AL.)</p><p>Shock Plate(L/R)</p></div>	<div><p>(AL.)</p><p>Chassis Mount</p></div>	<div><p>(AL.)</p><p>Differential Box</p></div>
P860091	P860092	P860093	R86570	R86571
<div><p>(COPPER)</p><p>Front Gear Box Lid</p></div>	<div><p>(COPPER)</p><p>Rear Gear Box Lid</p></div>	<div><p>(AL.)</p><p>Motor Mount</p></div>	<div><p>Wheel Rim</p></div>	<div><p>Crawler Battery (7.4V6200mAh/Plug:T)</p></div>
R86601	R86612	R86770	P860102	
<div><p>Antenna Pole</p></div>	<div><p>Drive Axle</p></div>	<div><p>9g/7.4v servo with metal gear</p></div>	<div><p>Hood Switch</p></div>	



PRODUCT QUALIFICATION CERTIFICATION

The product has conducted IQC (Input Quality Control) and full inspection before delivery. The manufacturer is responsible for quality assurance. Remote Control model is assembled manually, and then there may have some defects in the production process. Once the product is modified or incorrect operation, it cannot apply for replacement and return services, for the parts and accessories may be damaged. Please contact the retail seller for after-sales service when needed.

The product conforms to technical requirements of export safety regulations.

Factory Address: Huang Jiang Town, Dong Guan City, Guang Dong Province, China

Website: www.RGT-RACING.Com

Production Date: refer to packing instruction